







- 100W Dimmable RF LED Driver
- 100-240VAC Wide Input
- 4 Channels 12VDC/24VDC/36VDC Constant Voltage Output
- Power Factor > 0.85
- High Efficiency Up to 95%
- Enable to Control Monochrome, Dual Color, RGB and RGBW LED Lighting
- Compatible with A Variety of RF Remotes and Wall Mounted Control
- Can be WiFi Controlled While Working with A WiFi-RF Converter
- Radio Frequency: 868mhz





1. Pair RF Receiver with RF remote:

- 1.1. Connect and wire up the RF receiver correctly, power on.
- 1.2. Turn on the remote, click the "Learning Key" button on receiver, immediately click zone number then touch color wheel on remote, the connected led light on receiver flickers twice, means well paired. Note: one receiver can be paired with max 8 remote controls.

2. Delete the pairing:

S32003

- 2.1. Wire up the RF receiver correctly, power on
- 2.2. Hold the "Learning Key" button on receiver over 3 seconds until the connected led light on receiver flickers twice, means well deleted.