


S21001

Important: Read All Instructions Prior to Installation

Function introduction



Product Data


| Input Voltage | Output Current | Output Power | Remarks | Size(LxWxH) |
|------------------|-------------------|-----------------|------------------|-------------|
| 12-36VDC | 1x10A | 1x(120-360)W | Constant voltage | 95x37x20mm |

- Radio Frequency: 868/869.5/916.5/434mhz
- Waterproof grade: IP20

Safety & Warnings

- DO NOT install with power applied to device.
- DO NOT expose the device to moisture.

Wiring Diagram




Pair/delete the pairing with RF remote

- 1.Do wiring according to connection diagram.
- 2. Pair RF Receiver with RF remote: please refer to the instruction of the remote that you would like to pair with.
- 3. Delete the pairing:
- (1) Wire up the RF receiver correctly, power on.
- (2)Press and hold down the "Learning Key" button on receiver for over 3 seconds until the connected light flashes, which means well deleted.

PUSH DIM:

While connected with PUSH LV, click the button to switch ON/OFF lights. Press and hold down the button to increase/decrease light intensity.

Product Dimension



The Light Group AS, Sagmyra 2A, 4624 Kristiansand, Norway