

# INSTRUCTION

**SRGV/1500**  
**SRGSV/1500**



**REGIOLUX**

Regiolux GmbH  
Hellinger Str. 3  
D-97486 Königshausen/Bay.  
T 09525 89-0  
<http://www.regiolux.de>  
[info@regiolux.de](mailto:info@regiolux.de)

**Achtung:**  
Leuchte nicht öffnen!  
Garantieverlust!

**Attention:**  
Don't open the luminaire!  
Loss of Guarantee!

**Attention:**  
N'est pas ouvrir le luminaire!  
Perte de garantie!

**Atención:**  
Non abrir la luminara!  
Pérdida de garantía!

1000 mm

SRT

11  
10  
9  
8  
7  
6

L3  
L2  
L1  
PE  
N

ETM

OFF ON

PIN1 PIN2

OFF - OFF ~4800 lm / 29W  
OFF - ON ~5900 lm / 36W  
ON - OFF ~7000 lm / 43W  
ON - ON ~8100 lm / 51W

(1,2,3)

klick!

klick!

push! klick!

push! klick!

max. 1mm

**SRTE + SRGV + SRBAS = IP40!**    **SRTE + SRGSV + SRBAS = IP54!**  
**SRTE + SRGV + SRBKS = IP40!**    **SRTE + SRGSV + SRBKS = IP54!**

SRTE + SRGV / SRGSV + SRBAS = IP20!  
SRTE + SRGV / SRGSV + SRBKS = IP20!  
SRTE + SRGV / SRGSV + SRBA = IP20!  
SRTE + SRGV / SRGSV + SRBK = IP20!

**Demontage**

max. 4mm

max. 45°

max. 45°