


Important: Read All Instructions Prior to Installation

Function introduction



Output	RF signal
Operation Frequency	869.5MHz
Power Supply	3V(1xCR2025 battery)
Operating temperature	0-40°C
Relative humidity	8% to 80%
Dimensions	136.3x38.9x10.7mm

- Control 4 zones of RF receiver
- Dual color controller
- Compatible with universal serie RF receiver
- 1 receiver can be paired by max 8 different remote controls.
- Waterproof grade: IP20

Safety & Warnings

- This device contains a button lithium battery that shall be stored and disposed properly.
- DO NOT expose the device to moisture.

Operation

1. Pair with RF receivers:

Turn on the remote → Click "RF Code Key" on RF receiver → click a zone number 1/2/3/4 on the remote → Click any of the four buttons CW WW * *


→ LED lights connected with the RF receiver will flicker once → The receiver is paired with the remote successfully.

Play the remote after pairing:

Turn on the remote → Click the paired zone number/numbers → Click the other buttons to do the operate

How to delete the pairing:

Press and hold down "RF Code Key" on the receiver for over 3 seconds until connected LED lights flicker twice, which means the pairing is deleted successfully.



Note: Before the first use, please remove the protective film on the battery.

Back side